

STEPS OF 3G CONNECTION

A5S Support currently:

HUAWEI:

E261/E173/E353s/E1780/E177/E153/E1750/E1752Cu/E180/E156G/E3131/E303S

ZTE: MF190

Step1: Put 3G USB, Box will show when find it.




Select “3G Dongle” in menu “Network Config”



Step 2: Go **Setup**, put right **Dial Set** and **APN**



Step 3: Press **Connect and waiting.**



Step 4: It will show Network Type and Signal quality when it connects.

